




Pump unit with climatic controller for two heating circuits: mixed and direct; control of contact with boiler (heat source) for its starting and turning off. The unit, by reading the outside temperature, sets the correct supply temperature for both circuits, mixed and direct, on the basis of the set up climatic curves. **N.B.: the direct circuit, if present, needs an additional pump unit (optional) and of its temperature sensor TR/P4; to purchase it please refer to our Modvlvs catalogue at the section “Direct pump units”**

Wilo Yonos PICO 25/1-6 and Wilo Yonos PICO 25/1-8 circulating pump with built-in differential control: working with constant Δp or variable Δp .



① **Constant Δp :** or heating circuits with a stable pressure drop (f.i. underfloor heating) or plants (f.i. radiator heating) where the pressure drop of pipes is negligible in comparison with the pressure drop of the thermostatic radiator valves, or where independently from open thermostatic radiator valves, same differential pressure is requested.

② **Variable Δp :** in order to achieve the max energy saving and noise reduction. It is recommended in plants where the pressure drop of the pipes is higher than the pressure drops of the regulating valves, or more simply, when the requested differential pressure is decreasing when the flow comes down.

③ **Automatic air vent program:** turn the selector to this position at the first starting of the installation. The program, the duration of which is 10 minutes, starts the motor of the circulating pump alternately at low and high speed making the agglomeration of air bubbles towards the de-aeration points of the installation. **Once the program is finished turn the selector to the preselect mode: Δp constant or Δp variable.**



Typical curves of the pump units and of the circulating pump energy consumption from 4 up to 40 W (Wilo Yonos PICO 25/1-6) and 4 up to 75 W (Yonos PICO 25/1-8)




MIXING VALVE WITH SERVOMOTOR


3-way mixing valve with bi-directional servomotor with an operating range of 90°; led of activity in opening and closing mode. Selector for manual working with the indicator handwheel. A special connector allows to replace the servomotor in case of failure or bad working without having to operate on electric wires.

Kvs Value of the mixing valve: 10,0.

The model **M33** is supplied with a built-in by-pass into the body of the mixing valve. The built-in by-pass has an adjustable flow up to 50% of the total flow rate of the valve (especially suitable for underfloor heating installations).

Kvs Value of the mixing valve: 15,0.





20 mbar CHECK VALVE

Always inside the return way ball valve (B), it prevents the natural circulation of the fluid (gravity circulation).



To prevent the natural circulation, the check valve must be in operating mode, that is when the ball valve is completely open.

The nick on the knob, near the temperature indication of 60°C, must be in axis with the return way.



To fill or to empty the installation, the Check Valve must be excluded, by rotating the handle by 45° clockwise, starting from the complete open position (see picture at left).

The nick on the knob, near the temperature indication of 60°C, must do a 45° angle with the return way.



To service the installation, the ball valve must be closed by rotating the handle by 90° clockwise.

The nick on the knob, near the temperature indication of 60°C, must do a 90° angle with the return way.


SERVICE

To service / replace the circulating pump or the mixing valve, close the ball valves (A), (B), (C) and (D) by rotating the handles clockwise. Once the service is finished, open the four ball valves and put again the installation under pressure.

FASTENING THE PUMP UNIT



If there is not a manifold, the pump unit can be fastened to the wall or to the storage tank thanks to a special back plate, as shown.

EPP insulation box, measurements: 250x466x215 mm.



Back fixing holes on the plate suitable for M8 screws.

Special openings into the insulation box allow the fastening without dismantling the unit.



TECHNICAL FEATURES

PN 6, max temperature 110°C.
(max. 40°C ambient temperature and 95°C fluid temperature).

External connections: 1" Female.

FIELD OF UTILIZATION

For power up to 35 kW (with Δt 20 K) and maximum flow of 1500 l/h.

Kvs value: 6,0. Approximate data calculated with Wilo Yonos PICO 25/1-6 circulating pump (6 m nominal lifting power).

For power up to 20 kW (with Δt 8 K) and maximum flow of 2150 l/h.

Kvs value: 6,0. Approximate data calculated with a 6 Wilo Yonos PICO 25/1-8 circulating pump (8 m nominal lifting power).

For an accurate measuring or higher flows, please refer to the curves of the circulating pumps, (constant Δp or variable Δp) shown in the first page.

CLIMATIC CONTROLLER "CLIMA 4"

The climatic controller is supplied already pre-wired to the circulating pump, to the servomotor of the mixing valve and to the contact sensor S2 (TR/S1,5) for the supply mixed way. The power supply cable, also pre-wired, must be connected to the electric system 230 VAC only after having connected the temperature sensors, the circulating pumps or the valves (if present in the selected hydraulic scheme).

To do these operations use only skilled workers.

Please install the controller following the here below directions:



Picture 1: Connection of the sensors to the sensor box

✓ Connect temperature sensors (all are PT1000)

All the wirings must be done by means of the terminals inside the "sensor box", in accordance with the scheme of the *picture 1*. The sensor box must be fixed to the wall near the pump unit.

S1: outside temperature sensor TA52. The wiring must be done by the installer by means of cables with a minimum diameter of 0,75 mm² to a maximum length of 30 m. For longer distances, the diameter of the cable must be increased and the resistance of the overall cable-sensor must be checked in accordance with the values shown in *table 1* (by connecting the wirings it is not necessary to respect the "polarity").

S3: Contact temperature sensor TR/P4 of the direct circuit (optional).

S4: Dip temperature sensor TT/P4 of buffer tank or hydraulic switcher.

ground: connect the second cable (white) of the S1, S3 and S4 sensors to the multiple terminal.

RC21 (1): connect it to the terminal 1 of the room thermostat RC21 (optional).

RC21 (2): connect it to the terminal 2 of the room thermostat RC21 (optional).

RC21 (3): connect it to the terminal 3 of the room thermostat RC21 (optional).

Table 1: Resistance/temperature for wiring the sensors

| °C | 0 | 10 | 20 | 30 | 40 | 50 | 60 | 70 | 80 | 90 | 100 |
|----|------|------|------|------|------|------|------|------|------|------|------|
| Ω | 1000 | 1039 | 1077 | 1116 | 1155 | 1194 | 1232 | 1270 | 1308 | 1347 | 1385 |



Picture 2: Connection of the contact sensor to the supply way

✓ Connect the contact sensor TR/S1,5


Once the wiring of the sensors to the sensor box is finished, fix the contact sensor S2 (TR/S1,5) on the supply pipe after the ball valve with in-handle thermometer (coded red), by means of the clamp supplied as outfit, as shown in the *picture 2*. Moreover we recommend to put a thin layer of heat conductor paste between the sensor and the pipe.

Room thermostat RC21 (optional)

The use of the room thermostat allows the remote control of the system. In fact it is possible to manually counterbalance the supply temperature according to the requirements or, otherwise, to do it automatically in accordance to the room temperature, by putting in action the thermostat mode on the controller (look it up in its manual).

Selector of the function mode: automatic, day, night.

N.B: the climatic controller "Clima 4" together with the room thermostat RC21, allows to select the influence of the thermostat control only on the mixed circuit, only on the direct circuit or on both the circuits.




When you connect the room thermostat it is necessary to keep away the white small cable that makes a bridge between the clamps RC21 (1) and ground in the sensor box.

HYDRAULIC SCHEMES “CLIMA 4”

✓ Mixed circuit

By means of this hydraulic scheme a mixed circuit can be controlled.



S1: outside temperature sensor TA52.


Attention: put the sensor always toward the north and anyhow far from any heat source.

S2: contact temperature sensor TR/S1,5 to be fixed to the supply pipe.

S4: operating on the connections inside the sensor box (*pict.1*), disconnect the dip sensor of the buffer/hydraulic switcher, because not managed by this hydraulic scheme.

✓ Mixed circuit with boiler command

With this hydraulic scheme it is possible to manage a mixed circuit and to control the starting of the boiler by means of a zero potential contact when the temperature detected by S4 is less than the one requested by the circuit.



S1: outside temperature sensor TA52.

Attention: put the sensor always toward the north and anyhow far from any heat source.

S2: contact temperature sensor TR/S1,5 to be fixed to the supply pipe.


S4: operating on the connections inside the sensor box (*pict.1*), disconnect the dip sensor of the buffer/hydraulic switcher, because not managed by this hydraulic scheme.

Boiler contact: connect the boiler to the zero potential contact of the climatic controller between the clamps R5 and R5I as shown in *pict.3*. To do this operation you must open the electronic controller by means of the screw in the centre to remove the cover (please refer to the manual of the controller).

✓ Mixed circuit with buffer tank or hydraulic switcher and boiler command

With this hydraulic scheme it is possible to manage a mixed circuit with a buffer tank or with an hydraulic switcher.

It is also possible to control the starting of the boiler by means of a zero potential contact when the temperature detected by S4 is less than the one requested by the circuit.



S1: outside temperature sensor TA52.

Attention: put the sensor always toward the north and anyhow far from any heat source.


S2: contact temperature sensor TR/S1,5 to be fixed to the supply pipe.

S4: dip temperature sensor TT/P4 to be put into the buffer tank or into the hydraulic switcher.

Boiler contact: connect the boiler to the zero potential contact of the climatic controller between the clamps R5 and R5I as shown in *pict.3*. To do this operation you must open the electronic controller by means of the screw in the centre to remove the cover (please refer to the manual of the controller).

✓ Mixed circuit and direct circuit

By means of this hydraulic scheme a mixed circuit and a direct circuit can be controlled.



S1: outside temperature sensor TA52.

Attention: put the sensor always toward the north and anyhow far from any heat source.

S2: contact temperature sensor TR/S1,5 to be fixed to the supply pipe.

S3: contact temperature sensor TR/P4 of the direct circuit (*optional*). To be fixed on the supply pipe of the second circuit, outside the insulation box, by means of the clamp supply as outfit, as shown in *pict.2*. We recommend to put a thin layer of heat conductor paste between the sensor and the pipe. Operating on the connections inside the sensor box (*pict.1*), connect the sensor to the clamp S3.

R4: heating circulating pump of the direct circuit 2. Connect the circulating pump cables to the clamps of the climatic controller (*pict.3*), following the sequence here below indicated:

✓ brown cable to the clamp R4

✓ blue cable to the terminal board neutral N


✓ yellow/green cable to the ground metal clamp PE

To do this operation you must open the electronic controller by means of the screw in the centre to remove the cover (please refer to the manual of the controller).

S4: operating on the connections inside the sensor box (*pict.1*), disconnect the dip sensor of the buffer/hydraulic switcher, because not managed by this hydraulic scheme.

✓ Mixed and direct circuits with boiler command

With this hydraulic scheme it is possible to manage one mixed circuit and one direct circuit. It is also possible to control the starting of the boiler by means of a zero potential contact when the temperature is less than the one requested by the circuit.



S1: outside temperature sensor TA52.

Attention: put the sensor always toward the north and anyhow far from any heat source.

S2: contact temperature sensor TR/S1,5 to be fixed to the supply pipe.

S3: contact temperature sensor TR/P4 of the direct circuit (optional). To be fixed on the supply pipe of the second circuit, outside the insulation box, by means of the clamp supply as outfit, as shown in pict.2. We recommend to put a thin layer of heat conductor paste between the sensor and the pipe. Operating on the connections inside the sensor box (pict.1), connect the sensor to the clamp S3.

R4: heating circulating pump of the direct circuit 2. Connect the circulating pump cables to the clamps of the climatic controller (pict.3), following the sequence here below indicated:

- ✓ brown cable to the clamp R4
- ✓ blue cable to the terminal board neutral N
- ✓ yellow/green cable to the ground metal clamp PE


To do this operation you must open the electronic controller by means of the screw in the centre to remove the cover (please refer to the manual of the controller).

S4: operating on the connections inside the sensor box (pict.1), disconnect the dip sensor of the buffer/ hydraulic switcher, because not managed by this hydraulic scheme.

Boiler contact: connect the boiler to the zero potential contact of the climatic controller between the clamps R5 and R5I as shown in figura 3. To do this operation you must open the electronic controller by means of the screw in the centre to remove the cover (please refer to the manual of the controller).

✓ Mixed and direct circuits with buffer tank or hydraulic switcher and boiler command

With this hydraulic scheme it is possible to manage one mixed circuit and one direct circuit with a buffer tank or with an hydraulic switcher. It is also possible to control the starting of the boiler by means of a zero potential contact when the temperature detected by S4 is less than the one requested by the circuit.



S1: outside temperature sensor TA52.

Attention: put the sensor always toward the north and anyhow far from any heat source.

S2: contact temperature sensor TR/S1,5 to be fixed to the supply pipe.

S3: contact temperature sensor TR/P4 of the direct circuit (optional). To be fixed on the supply pipe of the second circuit, outside the insulation box, by means of the clamp supply as outfit, as shown in pict.2. We recommend to put a thin layer of heat conductor paste between the sensor and the pipe. Operating on the connections inside the sensor box (pict.1), connect the sensor to the clamp S3.


R4: heating circulating pump of the direct circuit 2. Connect the circulating pump cables to the clamps of the climatic controller (pict.3), following the sequence here below indicated:

- ✓ brown cable to the clamp R4
- ✓ blue cable to the terminal board neutral N
- ✓ yellow/green cable to the ground metal clamp PE

To do this operation you must open the electronic controller by means of the screw in the centre to remove the cover (please refer to the manual of the controller).

S4: dip temperature sensor TT/P4 to be put into the buffer tank or into the hydraulic switcher.

Boiler contact: connect the boiler to the zero potential contact of the climatic controller between the clamps R5 and R5I as shown in pict.3. To do this operation you must open the electronic controller by means of the screw in the centre to remove the cover (please refer to the manual of the controller).



CLIMA 4 Connection terminal board



ATTENTION:

The left side of the multiple terminal is usable only at low voltage (f.i. 12 VAC/DC)



DANGER:

The right side of the multiple terminal is usable only for 230 VAC 50-60 Hz voltage electrical supply



Picture 3: Multiple terminal of the climatic controller