



VIEW



PERFORMANCE VIEW


OPERATION STATUS



ALARM STATUS

- Blocked
- Supply voltage low
- Electrical error

SETTING MENU



KEY LOCK



SELECTION

CONTROL MODE	MODE	UPM3 xx-50	UPM3 xx-70	
PROPORTIONAL PRESSURE		1	1	
PROPORTIONAL PRESSURE		2	2	
PROPORTIONAL PRESSURE		3	3	
PROPORTIONAL PRESSURE		AUTO _{ADAPT}	AUTO _{ADAPT}	
CONTROL MODE	MODE	UPM3 xx-50	UPM3 xx-70	
CONSTANT PRESSURE		1	1	
CONSTANT PRESSURE		2	2	
CONSTANT PRESSURE		3	3	
CONSTANT PRESSURE		AUTO _{ADAPT}	AUTO _{ADAPT}	
CONTROL MODE	MODE	UPM3 xx-50	UPM3 xx-70	
CONSTANT CURVE		1	1	
CONSTANT CURVE		2	2	
CONSTANT CURVE		3	3	
CONSTANT CURVE		MAX	MAX	